## MEASURING INSTRUCTIONS



Using the lettered disc, choose the stud which fits in the mast slot with the least amount of side-to-side play.



Move the stud up the mast groove as far as you can reach to ensure that the slot width is uniform



Using one of the numbered discs, choose the stud which fits inside your groove with the least amount of fore-and-aft play. The flanged stud end may be inserted through the mast gate or anywhere along the groove by first turning it 90°.



As before, check the fit in several places to ensure consistent size. List the number on the ordering page as well.

Once you are satisfied that you have the proper match, list the letter on the order form.

For external track applications, supply the width of the existing track to the nearest 1/16 inch.